



Tech Support: 360-687-4530  
tech\_support@trailtech.net

## INSTALLATION INSTRUCTIONS FOR TRX450R STOCK LOCATION LIGHTS

### STEP 1: REMOVE STOCK LIGHT ASSEMBLY ENTIRELY

### STEP 2: INSTALL TRAIL TECH LIGHTS USING PHOTOS BELOW FOR GUIDANCE

Attach the mounting plate to the quad's frame using the two barrel cylinders and the four screws included in the parts bag. The upper screws are M6 buttonheads, and the two lower screws are M6 allen heads. The washers should be used with the M6 allens. Loctite is recommended.

### STEP 3: FOLLOW WIRING INSTRUCTION SHEET TO WIRE INTO STOCK LIGHTING HARNESS.

**Wire Color Information:**      Green = Ground or negative      Blue = High Beam      White = Low Beam



### LIMITED WARRANTY

Trail Tech Inc. warrants Trail Tech handlebar and bar clamp products to be free from defects in material and workmanship under normal use and if properly installed for a period of 90 days from date of purchase. If found to be defective as mentioned above, it will be replaced or repaired. This shall constitute the sole remedy of the purchaser and the sole liability of Trail Tech Inc. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representations whether expressed or implied, including any limited warranty of merchantability or fitness. In no event shall Trail Tech Inc. be liable for special or consequential damages.