

AIMING DUAL-SPORT X2

ADJUST LOW-BEAM ANGLE:

1. Turn the two screws shown below to adjust the beam.
 - 1A. **LOOSEN** the two screws to **LOWER** the beam angle.
 - 1B. **TIGHTEN** the two screws to **RAISE** the beam angle.

The two screws are not need to be snug against the back of X2.

